

OTS PB and OTS AF Range

Fully automatic insulating oil dielectric breakdown testing



- NEW Pinyin Chinese Text Input
- NEW IEC60156-2018
- NEW IEC60156-2018 V for Viscous Oils
- NEW IEC60156-2018 Annex A
- NEW IEC60156-2018 Annex A (V) for Viscous Oils
- NEW GBT 507-2002 Chinese Standard
- NEW Chinese language on screen
- NEW Withstand tests
- Full Range to suit all user needs
- Easy adjust locking electrode gap
- Fast precision breakdown detection
- Ultra-fast HV switch off time
- Suitable for mineral, ester and silicone oils

DESCRIPTION

Megger's range of automatic oil test sets performs accurate breakdown and withstand voltage tests on mineral, ester and silicone insulating liquids. Common across the range precision, shatter proof test vessels are easy to clean and provide repeatable results, whether they are used in the field or laboratory featuring lock in precision electrode gap setting adjustment wheels. The transparent, shielded lid and large test chamber allows easy access to the test vessel, enabling users to see what is happening within the test chamber.

All of the current test standards world wide are preloaded in the instrument for convenient automatic operation, however should a new test standard or an existing standard be amended there are 3 custom tests that can be configured to the new requirements. This enables testing to continue to cover the short period while Megger updates the test procedure files. New updated files are then downloaded by the user and installed into the test instrument via a USB memory stick / flash drive.

Test results are identified either by a serial number or asset ID and are time and date stamped. The Megger asset and data management software, PowerDB Lite, is bundled at no extra cost providing an excellent tool for downloading and printing results. An internal printer provides a hard copy of results. Ink based printout ensures durability at all temperatures. USB flash drive for easy transfer of test results, external USB printer and on the AF model a barcode scanner.

User safety is paramount and Megger have designed independent and dual redundant high voltage cut-off circuitry to ensure safety. During a test the operator can terminate by pressing any button on the keyboard which will remove high voltage immediately and abort the test. The transparent lid provides ample visibility within the chamber yet is protected and electrically shielded by a screen with multiple links to instrument ground.

OTS PB models

These 60 kV and 80 kV oil test sets are small and the lightest on the market with weight ranging from 16.8 kg to 20.8 kg depending on model configuration. The transport case and carry bag are optional accessories. The carry bag has pouches for electrode accessory pack, leads, quick user guide, paper roll etc. these units supplied mains powered and battery operated for additional flexibility in portable applications. All PBs are fitted with NiMH batteries.

OTS PB and OTS AF Range Fully automatic insulating oil dielectric breakdown testing

OTS AF models

These 60 kV, 80 kV and 100 kV models have a much larger test chamber for even easier access and cleaning, particularly useful in a lab environment. They are fitted with a 12 key alpha-numeric keypad to facilitate entry of test ID, file names, notes etc. Alpha characters are entered by repetitive pressing on a key. The AF models also have the ability to use a USB barcode reader to scan oil sample barcode labels, ideal for better integration within a laboratory.

APPLICATION

Monitoring and maintenance of oil quality is essential in ensuring the reliable operation of oil filled electrical equipment. Codes of practice have been established in many countries that include several different types of test on insulating oils.

One of the fundamental tests of oil quality is the breakdown voltage test, which is a measure of the oil's ability to withstand electric stress. A low breakdown voltage can indicate the presence of contaminants such as water or conducting particles.

In addition to the breakdown test, the withstand test is a measure of the oils ability to withstand a constant electrical stress. Failure to achieve this also indicates contaminants.

Care should be taken to ensure the process of sampling oil and subsequent testing does not in any way contaminate it with foreign objects. Cleaning vessels between oil tests should be a rinse with the next sample, never clean with fibrous materials. To ensure an accurate reading set gap carefully and lock adjusting wheels.

Refer to the OTSVesselPrep--2007-993_AN_en_V0# for more details.

FEATURES AND BENEFITS

COMMON ACROSS PB AND AF

- Lock in precision oil vessel lockable gap setting
- Flat electrode gap gauges that will not damage electrodes
- Oil temperature is measured continuously so it can be determined whether the oil test sample is within the range allowed by the test standards before the test is started
- QVGA colour display with adjustable backlight (easy to read in sunlight or dark conditions)
- Large, easy clean test chamber with oil drain
- High visibility test chamber
- Safe operation with dual redundant micro switches
- Intuitive user interface
- Fully automatic operation with preloaded international test standards
- User configurable test sequences to cover transition period of new / updated test standards (standards maintained via USB updates from Megger)
- All instruments supplied with one 400 ml test vessel in the box as standard
- Built onto a rigid box section chassis to prevent flexing on impact that otherwise would damage the transformer
- Unique built in chamber drain pipe for easy removal of oil accidentally spilt in test chamber, this can easily be connected to a lab waste system
- Selecting favourite tests speeds up selection by only displaying the standards regularly used by the user

OTS PB ADDITIONAL FEATURES AND BENEFITS

- Small and lightweight, lightest on the market starting at 16.8 kg
- Mains and battery powered for portable applications

OTS AF ADDITIONAL FEATURES AND BENEFITS

- Barcode scanning capability for oil sample ID
- Extra large test chamber for ease of use in high productivity application
- 12 key alpha-numeric keypad to facilitate entry of test ID, file names, notes etc.



COMMON PB AND AF OPTIONAL ITEMS

- Voltage check unit (VCM100D/VCM80D)
- 150 ml test vessel.

OTS60PB and OTS80PB OPTIONAL ITEMS

- Carry bag
- Transport case

OTS60AF, OTS80AF and OTS100AF OPTIONAL ITEMS

Barcode scanner (USB)

AVAILABLE UPGRADE

To update your OTS to the new IEC60156-2018 standard please contact your local Megger Authorised Sevice Centre for details.

OTS PB and OTS AF Range Fully automatic insulating oil dielectric breakdown testing

	ommends a separate test vessel is used for luid to be tested ure proof feature					
		OTS60PB	OTS80PB	OTS60AF	OTS80AF	OTS100AF
Standard items						
Internal printer						
NiMH battery						
Power cord						
Full electrode se	et - IEC and ASTM					
OTS Range Diff	ferentiating Features					
	60 kV					
Max test voltage	80 kV					
voltage	100 kV					
	Mains and NiMH battery operation					
Power Supply	Mains only operation					1
	Internal test result memory					
Data	Download results to USB stick					
management	Barcode scanning capability					
	Keypad for easy asset ID and memo entry					
	Tough display and chamber lid					
	Low cost shatter proof test vessel					
Ruggedness	Large corner protecting rubber feet					
	Rugged non-flex construction					
	Transport case		*			
Transport	Protective carry case		*			
	Light weight (<20.8 kg) one man carry					
	Low cost test vessel		_		_	
Operating costs	(Vessel of each oil **)	•	•			
COSIS	Annual full calibration					
	Fast favourite list selection					
	Fully automatic test sequence					
Test standards	Test standards update via USB device ***					
	Custom tests					
	Easy pour / clean vessel design					
Cleanliness	Large test chamber (easy access)					
	Test chamber spilt oil drain					
	Continuous oil temperature measurement					
Accuracy	Lockable thumb wheel adjustable electrode gap					
2	Voltage output verification unit available					

OTS PB and OTS AF Range Fully automatic insulating oil dielectric breakdown testing

SPECFICATIONS

Test voltage

OTS60PB	0 to 60 kV rms maximum (30 kV - 0 - 30 kV)
OTS80PB	0 to 80 kV rms maximum (40 kV - 0 – 40 kV)
OTS60AF	0 to 60 kV rms maximum (30 kV - 0 - 30 kV)
OTS80AF	0 to 80 kV rms maximum (40 kV - 0 - 40 kV)
OTS100AF	0 to 100 kV rms maximum (50 kV - 0 - 50 kV)

Voltage rise time

0.5 kV/s, 2.0 kV/s or 3 kV/s depending on selected test standard and 0.5 kV/s up to 10kV/s in custom test

Voltage rise time accuracy

better than 5%

Voltage resolution and accuracy Up to 5 kV/s: 0.1 kV +/- 1% +/-2 digits 5 kV/s up to 10 kV/s: 0.1 kV +/- 1% +/-4 digits

IRAM 2341

IS 6792-2017

Programmed test sequences

- ASTM D 1816-12
- ASTM D 1816-12E (ester oil)
- ASTM D 877A-19
- ASTM D 877B-19
- AS1767.2.1
- BS EN 60156-96
- BS 5730a AD 30 kV
- BS 5730a AD 40 kV
- BS 5730a BCEF 22 kV
- BS 5730a BCEF 30 kV
- BS 148 / EN 60156
- CEI EN 60156-95
- Custom 5, 6 and 10
- GB/T 507-2002
- GOST 6581-75
- IEC 60156-95
- IEC 60156-2018
- IEC 60156-2018V
- IEC 60156-2018
 Annex A
- IEC 60156-2018
 Annex A (V)

- IS 6792-2-2017
 JIS C 2101-99 (M)
 JIS C 2101-99 (S)
 NF EN 60156
 PA SEV EN60156
 SABS EN60156
- UNE EN 60156
- VDE0370 part 5
- Withstand A
- Withstand B

Vessels

400 ml (standard) 150 ml (accessory)

Carefully designed test vessels manufactured from the most chemical resistant clear polymer on the market provides tried and tested reliable test results. Featuring precision electrode alignment and adjustment wheels that lock electrodes in position, the option of a 150 ml vessel for low volume oil samples is also available

Temperature measuring range

10 °C to 65 °C (ASTM D877 requires oils to be within 20 °C and 30 °C) (IEC 60156 required oil to be within 15 °C and 25 °C)

Temperature sensor resolution

	1 °C
Power supply	Line voltage 85 to 265 VAC Line frequency 50/60 Hz
Battery type	NiMH 24 V 2 Ah (OTS60PB or OTS80PB ONLY)
Power source:	85 V – 265 V 50/60/400 Hz input. Portable unit can be powered from 85 V – 265 V or its internal battery.
Battery life:	10 test sequences up to 70 kV using 2 Ah battery
Charge retention at 20°C:	NiMH 50% discharged after 1 month
Battery charging:	Automatic when connected to power source. Charge time 16 hours slow or 2 hour fast charge to >90%
Interface	2 x USB type-A (Flash drive, printer) , 1 x USB type-B (Factory use)
Internal printer	Matrix impact printer Paper 57.5 mm wide
External printer:	supports PCL3, PCL6, PS and EPS
Protection	Dual safety micro switches on chamber cover
Display	3.5 in display. 320 x 240 QVGA colour display with backlight
Operating tempe	rature range and humidity
	0 °C to +50 °C. 80% RH at 40 °C
	non-condensing conditions
Storage tempera	ture range and humidity
	-30 °C to +65 °C . 95% RH at 40 °C
	non-condensing conditions
Maximum altitud	le
	1000 m
IP rating	IP30
Safety	Designed in accordance with IEC61010

ir rating	IF 50
Safety	Designed in accordance with IEC61010
EMC	Light industrial IEC 61326-1 Class B,
	CISPR 22, CISPR 16-1 and CISPR 16-2



Dimensions

OTS60PB OTS80PB	520 mm x 340 mm x 250 mm 520 mm x 380 mm x 250 mm
OTS60AF OTS80AF OTS100AF	580 mm x 420 mm x 290 mm 580 mm x 420 mm x 290 mm 580 mm x 420 mm x 290 mm
Weight	
Weight OTS60PB OTS80PB	16.8 kg 20.8 kg

OTS80AF OTS100AF	30 kg 30 kg
Test vessels	1.1 kg (400 ml and 150 ml)
Language	English, French, German, Spanish, Czech, Dutch, Finnish, Italian, Norwegian, Polish, Portuguese, Russian, Swedish and Chinese



Oil 1Standards complied with and programmedMineral EsterMineral with and programmedMineral EsterAS1767.2.1•AS1767.2.1•AS1767.2.1•ASTM D 1816-12•ASTM D 1816-12•ASTM D 877A-19•ASTM D 877B-19•ASTM D 877B-19•		id Silicone		Elect optic	Electrode gap options (mm)	ap m)		Electro	Electrode shape options	ape	oil ctivit	_	0 	Voltage rise rate options	ise Sec	Breakd	Breakdown test sequence	eduence
		Silicone					F				options	suo	lat		2			
			1.0	2.0	2.5	2.54	4.0						0.5 kV/s	2 kV/s	3 kW/s	Number of tests	Intial stand time	Time between tests
	┝╺┝╺┝╺┝	•							•		•	•		•		9	5 mins	2 mins
	┝╼╎╼╎╸╎	•	-	-				•				•	•			5	3 mins	1 min 15s
		•	•	•								•	•			5	30 mins	1 min 15s
		•				•				•	•				-	5	2 mins	1 min
		•				•				•	•				•	1 x 5	2 mins (x5)	N/A
BS148 EN60156	_	•			•				•							9	5 mins	2 mins
BS 5730a AD 30 kV/40 kV		•	30	30 kV = 2.	5 40 kV	«V = 4.0	0	•	•	•	•	•		•		m	10s to 600s	N/A
BS 5730a BCEF 22 kV/30 kV		•	22	22 kV = 2.	5 30 k	30 kV = 4.0	0	•	•	•	•	•		•		4	10s to 600s	N/A
BS EN 60156-96									•			•		•		9	5 mins	2 mins
CEI EN 60156-95		•							•		•	•		•		9	5 mins	2 mins
Custom 5, 6 and 10		•		1.0	0 to 7.0			•	•	•	•	•	0.5 kV	kV/s to 10 kV/s) kV/s	5, 6 or 10	10s to 600s	10s to 600s
GBT 507-2002		•			•			•	•		•	•		•		9	5 mins	2 mins
GOST 6581-75		•			•			•				•		•		6	10 mins	5 mins
IEC 60156-95		•			•			•	•		-	•		•		6	5 mins	2 mins
IEC 60156-2018		•			•			•	•		-	•		•		6	5 mins	2 mins
IEC 60156-2018 (V)		•			•			•	•		•	•		•		9	15 mins	6 mins
IEC 60156-2018 Annex A		•			•			•	•		•	•		•		10	5 mins	1 mins
IEC 60156-2018 Annex A (V)		•			•			•	•		•	•		•		10	15 mins	3 mins
IRAM 2341	-	•			•			•	•		•	•		•		9	5 mins	2 mins



Continued	Oil types tested	rpes ed		Electrode gap options (mm)	ode g ns (mi	ap U	ш	lectro op	Electrode shape options	e	Oil stirring options	ם צ	Volta rate	Voltage rise rate options	se	Breakd	Breakdown test sequence	aduence
Standards complied with and programmed	Mineral Ester HMWH*	Silicone	1.0	2.0	2.5 2	2.54 4	4.0					h	0.5 kV/s	2 kV/s	3 kV/s	Number of tests	Intial stand time	Time between tests
IS6792 -2017	•	•					_			-				•		9	10 mins	2 mins
IS6792-2 -2017	•	•														9	10 mins	6 mins
JIS C 2101-99 (M)	•														•	5 x 2	2 mins	1 min
JIS C 2101-99 (S)															•	1 x 5	2 mins (x5)	N/A
NF EN 60156	•	•							•		•			•		9	5 mins	2 mins
PA SEV EN 60156	•	-							•							9	5 mins	2 mins
SABS EN 60156		-							-		-			-		9	5 mins	2 mins
UNE EN 60156		-							•			•		•		9	5 mins	2 mins
VDE 0370 part 5	•	-			•				•		-	•		-		9	5 mins	2 mins
Withstand A		-		2.5	.5 to 4.0						-			-		1	10s to 600s	N/A
Withstand B		-		2.5	.5 to 4.0									•		2	10s to 600s	N/A

* High Molecular Weight Hydrocarbon

OTS PB and OTS AF Range Fully automatic insulating oil dielectric breakdown testing

Description	Order Code	Description Ord		
OTF PB Models		Optional accessories		
)TS60PB		OTS IEC60156 Electrode set contents - supplie	d in accessory	
DTS60PB-EU	1014-525	case		
DTS60PB-UK	1014-526	12.7 mm spherical electrodes (2)		
DTS60PB-US	1014-527	36 mm mushroom electrodes (2) Magnetic stirrer bar (2)		
DTS60PB-AU	1014-528	Magnetic stirrer bar retriever (1)		
DTS80PB		Gap gauge set	1001-47	
DTS80PB-EU	1014-529	OTS ASTM D877/D1816 Electrode set contents	s – supplied in	
TS80PB-EU TS80PB-UK	1014-529	accessory case		
DTS80PB-US	1014-531	25.4 mm standard (sharp edges) cylindrical electro	des (2)	
DTS80PB-AU	1014-532	25.4 mm non-standard (round edges) cylindrical el	ectrodes (2)	
		36 mm mushroom electrodes (2)		
ncluded accessories (OTS PB models)		Magnetic stirrer bar (2)		
/essel 400 ml assembly (stirrer lid fitted)		Magnetic stirrer bar retriever (1) Gap gauge set	1001 47	
ull electrode set - IEC and ASTM			1001-47	
C and ASTM impeller rinter,		Full electrode set (covers IEC and ASTM stand	ards)	
liMH battery,		12.7 mm spherical electrodes (2) 36 mm mushroom electrodes (2)		
lectrode gauge set		25.4 mm standard (sharp edges) cylindrical electro	des (2)	
Calibration certificate		25.4 mm standard (shalp edges) cylindrical electro		
ower DB guide		Magnetic stirrer bar (2)		
Quick Start Guide		Magnetic stirrer bar retriever (1)		
TS Vessel Preparation Guide		Gap gauge set	1001-47	
		Vessel lid mounted impeller (ASTM or IEC)		
		for use with 400 ml vessel	1001-10	
OTF AF Models		Carry bag (padded) OTS80PB	1001-47	
TS60AF		Carry bag (padded) OTS60PB	1001-48	
TS60AF-EU	1014-533	Vessel 400 ml assembly (no electrodes supplied)	1001-47	
TS60AF-UK	1014-534	Vessel 150 ml assembly (no electrodes supplied)	1001-47	
DTS60AF-US	1014-535	VCM100D digital voltage checker	1001-10	
ITS60AF-AU	1014-536	VCM80D digital voltage checker	1001-80	
TS80AF		Printer paper, 20 rolls		
ITS80AF-EU	1014-537	(4 rolls supplied if printer configured)	1008-03	
TS80AF-UK	1014-538	Printer Ribbon Cassette	25995-00	
ITS80AF-US ITS80AF-AU	1014-539 1014-540	Barcode reader, USB	1001-04	
	1014-340	Transport case (with wheels)	1001-47	
TS100AF		ASTM alternative propeller shaft assy	1007-15	
TS100AF-EU	1014-541			
TS100AF-UK	1014-542	IEC alternative propeller shaft assy	1007-15	
ITS100AF-US ITS100AF-AU	1014-543 1014-544	Electrodes - Spherical (pair)	6220-48	
	1014-344	Electrodes - Mushroom (pair)	6220-58	
cluded accessories (OTS AF models)		Electrodes - Cylindrical (pair)	6220-48	
essel 400 ml assembly (stirrer lid fitted)		Electrodes - Non-standard cylindrical with		
rinter		0,5 mm edge radius (pair)	6220-53	
ull electrode set - IEC and ASTM		Electrode gauge set 1, 2, 2.5, 2.54, 4 mm	1002-14	
lectrode gauge set EC and ASTM impeller				
alibration certificate				
ower DB guide				
Duick Start Guide			(Alice)	
TS Vessel Preparation Guide				
		Res the Alex	L.	

OTS PB and OTS AF Range

Fully automatic insulating oil dielectric breakdown testing

	ORDERING
Description	Order Code
Calibration certificates	
Calibration Certificate OTS AF	1001-921
Calibration Certificate OTS PB	1001-920
UKAS Calibration Certificate OTS60 AF	1000-089
UKAS Calibration Certificate OTS80 AF	1000-091
UKAS Calibration Certificate OTS100 AF	1000-088
UKAS Calibration Certificate OTS60 PB	1000-090
UKAS Calibration Certificate OTS80PB	1005-943

SALES OFFICE

Megger Limited Archcliffe Road Dover CT17 9EN England T. +44 (0) 1304 502101 E. UKsales@megger.com www.megger.com ISO 9001 The word 'Megger' is a registered trademark



OTS60PB--OTS80PB--OTS60AF--OTS80AF--OTS100AF_DS_en_V10