

Tilt & Lift – Group Channel Set Up

Assuming you are working on more than 1 blind

Step 1: Disconnect the Power to all blinds apart from the one you are working with

Step 2: Select the desired channel (*eg channel 1*) of the blind in which you need to copy over

Step 3: Press and Hold the Programming Button on the back of the remote until the blind jogs once

Step 4: Select the Desired Channel or Group Channel you wish to paste in to

Step 5: Briefly Press and Release the Programming Button on the back of the remote (DO NOT HOLD) The blind should jog once

Step 6: Confirm that the blind works on both the single channel and the group channel as expected

Step 7: Now you can disconnect the Power to this blind in order to move on to the next