

Preparing 1 Door Tall Cabinet

Stock No.

To make assembly easier we recommend having two persons aid one another in assembly.


Item	Description	Quantity
1	Top Panel	1
2	Bottom Panel	1
3	Left Side Panel	1
4	Right Side Panel	1
5	Back Panel	1
6	Door	1
7	Front Kick Panel	1
8	Side Kick Panel	2
9	Shelf Panel	4
10	Foot Holder	4
11	Leg Leveller	4
12	M8 x 16mm bolt	16
13	M6 x 16mm bolt	12
14	12 x 7 x 5mm Flat Washer	1

33165

CABINET CONNECTION


Connect the side panels of two cabinets with (4) bolt M6 x 16mm and nut M6, and tighten with phillips screwdriver (not included).


Note: remove the drawers and open the doors before cabinet connection.





STEP 1:







STEP 2:

Insert the top panel (item 1) into the side and back panels. Lay the cabinet flat on the ground if necessary.




Insert the bottom panel (item 2) into the side and back panels. Lay the cabinet flat on the ground if necessary.






STEP 4:

Use packaging material to protect the unit. Attach the leg leveller (item 11) to foot holder (item 10). Insert bolt M8 x 16mm (item 12) through the foot holder into the cabinet.



Attach the front and side kick panel (item 7 and 8) to foot holder with bolt M6 x 16mm (item 13).




STEP 6:

Obliquely place the four shelf panels (item 9) in the cabinet, secure the shlef panels at four desired heights by carefully inserting the shelf edges into the flanges on left and right side panels. Make sure each shelf is level.

STEP 7:

Place the flat washer (item 14) into the hinge pin, algin the hinge pin on the bottom of the door with the hole on bottom panel, slowly and carefully insert the hinge pin into the hole. Algin the hinge pin on the top of the door with the hole on top panel, slowly and carefully insert the hinge pin into the hole.










Installing Worktop

Stock No.

33171, 33172, 33178, 33180, 33182, 33192, 33203, 33210

To make assembly easier we recommend having two persons aid one another in assembly.

Place the worktop on cabinets, align the pre-drilled holes in worktop with holes in cabinets, secure bolt M6 x 16mm through the top of the cabinets into the worktop pre-drilled holes.







Installing Back Panel / Wall Cabinet with Wall Brackets (Single & Double)

Stock No.

33196/33162


To make assembly easier we recommend having two persons aid one another in assembly.

STEP 1:

Attach wall bracket (single and double) to cabinet with bolt M8 \times 16mm, washer 18 \times 8 \times 1mm and spring washer 14 \times 8.8 \times 2.6mm, and tighten with wrench (not included).

STEP 2:


Attach back panel to wall bracket (single and double) with bolt M6 x 16mm, nut M6 and spring washer $12 \times 6.5 \times 0.8$ mm, and tighten with wrench (not included).






STEP 3:

Attach wall cabinet to wall bracket (single and double) with bolt M8 x 16mm, flat washer $8 \times 8 \times 1$ mm and spring washer $14 \times 8.8 \times 2.6$ mm, and tighten with wrench (not included)



STEP 4:


Connect the side panels of two cabinets with M6 x 16mm and nut M6, and tighten with wrench (not included).



CABINET CONNECTION

Connect the side panels of two cabinets with (4) bolt M6 x 16mm and nut M6, and tighten with wrench (not included).

Note: remove the drawers and open the doors before cabinet connection.









Installing Wall Bracket

Stock No.

33197, 33198

- Attach wall bracket (double) to back panel with (10) bolt M6 x 16mm, nut M6 and flat washer 12 x 6.5 x 0.8mm, and tighten with wrench (not included).
- Attach wall bracket (double) to wall cabinets and base cabinets / trolley with (8) bolt M8 x 16mm, flat washer 18 x 8 x 1mm and spring washer 14 x 8.8 x 2.6mm, and tighten with wrench (not included).
- Attach wall bracket (single) to back panel with (5) bolt M6 x 16mm, nut M6 and flat washer
 12 x 6.5 x 0.8mm, and tighten with wrench (not included).
- Attach wall bracket (single) to wall cabinets and base cabinets / trolley with (4) bolt M8 x 16mm, flat washer 18 x 8 x 1mm and spring washer 14 x 8.8 x 2.6mm, and tighten with wrench (not included).

