Precautions

Installation Notes

- Install in accordance with the IEE wiring regulations and building regulations.
- This product must be installed by a suitably competent person.

IMPORTANT

- ▶ Please read these instructions before commencing any work.
- Please retain these instructions for future reference.
- Please refer to product listing for detailed information.
- Remove all packaging before connecting to power supply.

Electrical

- Do not connect directly to mains electrical supply.
- Switch the power off at the mains supply before installing or maintaining this fitting.
- Ensure others cannot restore the electrical power supply without your knowledge.
- Ensure the product is in good working condition. If there is visible damage do not use.
- This product must be used with a good quality constant voltage LED driver. Ensure that the voltage output of the driver matches rated voltage of the LED tube.
- Connect the tube with correct polarity. Refer to the 'wiring' section for help.
- Ensure that the power capacity of the LED driver is greater than the total load of all the LED tube connected to it.
- The LED tube and cable should be protected by a fuse or equivalent device installed between the driver and LED tube and as close to the driver as possible
- Ensure that the current capacity of cable connecting the LED tube to the driver is greater than the maximum drawn by the tube and the cut off of any over-current protection (fuse).
- Protect the strip from static electricity

Mechanical

- Do not use the product if damaged. Do not use with worn or damaged wires or strip lights.
- The product will generate heat during use. It should be installed in a well ventilated location. Fully uncoil all cables. Do not cover or conceal.
- The tube should be mechanically supported with the recommended mounting accessories.
- Protect the tube from mechanical damage. Take care not to dislodge any components during installation. Ensure that wires connecting the tubes cannot be pulled.
- Ensure suspension accessories are correctly fitted.

Environmental

- The product should only be used in an environment with an ambient temperature between +5°C to +40°C.
- The temperature of the LED tube should never exceed 60°C when in operation.
- ► This product is not waterproof. Not suitable for permanent outdoor installation.
- Only install in a location free from chemicals, corrosives, gases and flammable materials.

Product Warranty

- 1. A warranty period is provided for products in normal use. For any faults arising during the period that are confirmed to be quality related by inspection by the company, a product of the same specification will be replaced for free.
- 2. The warranty does not cover any of the following:
 - (1) Any product damage due to usage not allowed in the instructions.
 - (2) Any product damage due to disassembling or wrong operation by the user.
 - (3) Severe appearence damage or deformation of the product.

LED Neon Tube Light



▶ RGB NTUBE LED Tube



by tagra®

User Manual

SKU: NTUBE-WW SKU: NTUBE-CW SKU: RGB-NTUBE















Precautions




Mounting



Fix mounting clip to surface with a screw and attach tube light. Always use at least 2 mounting clips.


WARNING: Do not attach mounting clip to ceiling.

Standing




- Unscrew tube holder from base plate.
- 2. Place tube light into tube holder and thread wire through the exit point.
- Screw tube holder back onto base plate.

Wiring




WARNING: This product must be installed by a suitably competent person. Check polarity (+/-) is correct before turning on. Incorrect polarity can cause damage to products.






SKU	Length (A)	Length (B)	Cable Length
NTUBE-0.5M	540mm	446mm	1000mm
NTUBE-1M	1040mm	946mm	1000mm
NTUBE-1.5M	1540mm	1446mm	1000mm
NTUBE-2M	2040mm	1946mm	1000mm

Available Accessories







SKU: NTUBE-STAND/BLK