




OPERATING INSTRUCTIONS



MEFF15350W – Fridge Freezer

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE USE

WHEN USING ANY ELECTRICAL APPLIANCE, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED


IMPORTANT – If the mains lead of this appliance becomes damaged then it must be replaced by the manufacturer's service agent, or a suitably qualified person using the same rated cable in order to avoid a hazard.



Getting to know your fridge freezer

DO NOT TURN ON THE FRIDGE FREEZER FOR 2 HOURS

After the fridge freezer is in place it needs to be left for 2 hours, to allow the coolant fluid time to settle.



- | | |
|----------------------------|-----------------------|
| 1. Fridge | 10. Fridge door |
| 2. Temperature control | 11. Egg tray |
| 3. Glass shelves | 12. Door shelves |
| 4. Water spout | 13. Fridge door seal |
| 5. Salad crisper cover | 14. Freezer door |
| 6. Salad/vegetable crisper | 15. Freezer door seal |
| 7. Freezer | 16. Fixed feet |
| 8. Freezer drawer | 17. Adjustable feet |
| 9. Power supply cord | |



Specification

Disposal information



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority for recycling advice.



This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the freezer.

Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

- **WARNING:** Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- **WARNING:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- **WARNING:** Do not damage the refrigerant circuit.
- **WARNING:** Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

The instructions shall include the substance of the following:

This appliance is intended to be used in household and similar applications such as

- Staff kitchen areas in shops, offices and other working environments;
- Farm houses and by clients in hotels, motels and other residential type environments;
- Bed and breakfast type environments;
- Catering and similar non-retail applications.



This appliance is not intended for use by persons including children with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with this appliance.

THERE ARE NO USER SERVICEABLE PARTS INSIDE AND THE CASING SHOULD NOT BE OPENED BY AN UNQUALIFIED PERSON

THIS APPLIANCE IS INTENDED FOR DOMESTIC USE ONLY

Electrical Connection

Ensure your supply is rated at 220-240v and 50/60Hz before operating the appliance. This refrigerator is fitted with a rewirable plug incorporating a 13amp fuse. In addition this appliance must be earthed or connected to an earthed supply. In the event of the fuse needing replacement then a 13amp fuse approved by ASTA to BS1362 MUST be used.

IMPORTANT: If the plug fitted is not suitable for your socket, then the 13amp plug supplied should be removed. Before wiring the appropriate plug, please note that the wires in this mains lead are coloured in accordance with the following code:

<i>BLUE</i>	<i>- Neutral</i>
<i>BROWN</i>	<i>- Live</i>
<i>GREEN & YELLOW</i>	<i>- Earth</i>

As the colours in the mains lead may not correspond to the coloured markings in your plug, proceed as follows:

Connect the BROWN wire to the terminal marked 'L' or coloured RED, Connect the BLUE wire to the terminal marked 'N' or coloured BLACK, Connect the GREEN & YELLOW wire to the terminal marked 'E' or coloured GREEN or GREEN AND YELLOW. If in doubt consult a suitably qualified electrician.



Installation

Location

When selecting a position for your fridge freezer, you should make sure the floor is flat and firm, and the room is well ventilated with an average room temperature of between 12°C and 32°C.

Avoid locating your fridge freezer near a heat source, eg cooker, boiler or radiator. Also avoid direct sunlight in sun lounges or conservatories. If you are placing your fridge freezer in an out-building such as a garage or annex ensure that the fridge freezer is placed above the damp course, otherwise condensation will occur on the fridge freezer cabinet.

Never place the fridge freezer in a wall recess or into fitted cabinets or furniture. When your fridge freezer is working, the grille at the back may become hot and the sides warm. To aid the air flow around the fridge freezer keep ventilation openings, in the appliance enclosure or in the built in structure, clear of obstruction. It must also be installed so that there is at least 7cm (2 ¾") of free space at the back, sides and above the fridge freezer.

The fridge freezer door can be fitted to open to either the right or the left, depending on its location. (see instructions on page 6)

Levelling the fridge freezer

Once the fridge freezer is sited in its final location, make sure it is level. To do this use the two levelling feet at the front of the fridge freezer. (If the fridge freezer is not level, the doors and magnetic seal alignments will be affected.)

Cleaning before use

Wipe the inside of the fridge freezer with warm water using a soft cloth. Wipe completely dry before replacing the shelves and baskets.

Before using your fridge freezer

Check that your power outlet is compatible with the plug supplied with the fridge freezer. If not, see the section called ELECTRICAL CONNECTION at the back of this booklet.

DO NOT SWITCH ON UNTIL TWO HOURS AFTER MOVING THE FRIDGE FREEZER to allow the coolant fluid time to settle.

Before placing any food in your fridge freezer, turn the fridge freezer on and wait for 24 hours, to make sure it is working properly and to allow the fridge freezer to fall to the correct temperature.



Using your fridge freezer

Switching on your fridge freezer:

1. Before connecting the fridge freezer to the mains supply make sure that the Temperature Control located inside the fridge freezer is set between **3** and **4**, which is the correct setting for use in a room of average temperature.
2. Wait 24 hours before placing food in the cabinet to allow for the fridge freezer to fall to the correct temperature.

Adjusting the temperature

The internal temperature of your fridge freezer is controlled by the Temperature Control. There are 7 settings. Position **7** makes the fridge freezer coldest. Position **1** makes it the warmest. To adjust the temperature, turn the Temperature Control to the preferred setting.

The temperature of the fridge freezer is best maintained around 0°C to +5°C. Avoid setting the thermostat too high otherwise this may reduce the temperature to a point where certain fresh foods may begin to freeze.

Noises inside the fridge freezer

If you have not owned a fridge freezer before, you may notice that it makes some rather unusual noises. Most of these are perfectly normal, but you should be aware of them!

GURLING, WHOOSHING

These noises are caused by the circulation of the refrigerant liquid in the cooling system. It has become more pronounced since the introduction of CFC free gases. This is not a fault and will not affect the performance of your fridge freezer.

HUMMING, PURRING OR PULSATING

This is the compressor motor working, as it pumps the refrigerant around the system.

Servicing and Maintenance

Repairs and maintenance of the authorized, qualified technician.



appliance should only be performed by an



***WARNING!** It is hazardous for anyone other than authorised personnel to carry out servicing or repairs which involve the removal of covers. Do not damage the refrigerant circuit.*

To avoid the risk of electric shock do not attempt repairs yourself.