## CHAUVIN ARNOUX

**PEL 104** 

PEL 106

20 78 \*



## Power and energy loggers, simultaneously

### PEL100, the loggers for efficient consumption!

- Ideal for all types of electrical cabinets and Low Voltage installations
- Implementation without cutting off the mains power supply
- Recording duration up to several months or years
- Breakdown of energy losses
- Characterization of electric motors



CHLENIN-

PEL 102

VER & ENERGY LOGGER





CHEAL WE A



DEL103

# APPLICATIONS

# **F**or sustainable, economical buildings, improve your energy efficiency

In the context of a worldwide approach for protection of the environment, Europe has set itself the goal of reducing consumption by approximately 30%. Today, more than 50% of energy consumption occurs in the industrial sector and buildings. Optimization of energy consumption is therefore crucial to fulfil the regulatory requirements.

The **PEL100** models are power and energy measurement loggers for all electrical installations. The measurements are made by means of current sensors and voltage inputs. They can be used to view all the electrical parameters and take advantage of the measuring, energy metering and communication functions.

They offer users all the measurements needed to carry out successful energy efficiency projects and ensure supervision of the electrical distribution system.

The **PEL100** family of energy meters makes it easy to add metering and measuring points in electrical cabinets affected by strong integration constraints. They are magnetized, so they are easy to position in any electrical cabinet without causing any difficulties once the cabinet is closed. The monitoring performed by the **PEL100**s provides the recordings to be compared with the period of reference.



# Monitoring and mapping of the consumption on a site

**PEL100** loggers catch every detail of the electrical consumption in a factory, workshop, building, agency, etc. They can be used simultaneously for real-time monitoring and comparative, historical consumption analysis.

# **U**se in networks & centralized consumption management

By setting up several **PEL100**s on a general electrical distribution system, for example, local authorities can control the different allocations of consumption, which is very practical for facilitating consumption management across a town district: street lighting network, lighting network for common areas, general single-phase distribution, three-phase distribution.

## Measuring the savings

The recordings made with the **PEL100** measuring instruments are time/date-stamped. This makes it very simple to measure the gain achieved by comparing the recordings before and after modifications to an installation. The analysis of the recording made with the **PEL100**s before the modifications corresponds to the period of reference. Various operations such as maintenance or improvement of the electrical network or equipment can then be carried out. A correctly-positioned **PEL100** will help you quickly pinpoint the areas where work is required, without wasting any time. A period of monitoring will help to show whether the solutions applied are sufficient and above all to measure the savings achieved. The monitoring performed by the **PEL100**s provides the recordings to be compared with the period of reference.

## **P**EL Transfer software

The PEL Transfer software can also provide a breakdown of the types of energy and their losses. Users have access to all the elements needed to establish the priority of their operations.

- Useful energy
- Active unbalance energy
- Active harmonic energy
- Non-active energy
- Reactive energy
- Distorting energy
  - Apparent energy



Balance

## APPLICATIONS

# A nalogue measurements

The **PEL106** can be used to identify each of the dysfunctions by recording external parameters such as the pressure, temperature, torque, etc.

Via its Bluetooth wireless link, it communicates with remote L452 dataloggers. The **PEL106**'s recording function can integrate up to  $2 \times 4$  analogue channels. The analogue channels complement the voltage, current and power measurements.

## Energy consumption of a motor, transformer station, etc.

When used with remote L452 loggers, the **PEL106** records analogue measurements (external parameters, up to  $2 \times 4$  channels) such as the temperature, pressure, motor torque, etc. It can also be used to analyse a temperature-affected motor, for example, or electrical transformer station.

### **Renewable energy**

The **PEL106**'s analogue measurement function offers the possibility of linking electricity generation to a wind speed or a hydro-electric current to a flow-rate.

It meets the requirements of the applications in the renewable energies sector, such as metering the energy linked to the strength of the wind, for example.

The **PEL106** accurately measures the energy efficiency of wind turbines, which depend on the wind speed, or hydro-electric dams, which depend on the water flow-rate, etc.





# **A** dvantages of the ANDROID application

Users can view the measurement results in real time on their ANDROID devices. The application is multilingual.

A software sensor developed by Chauvin Arnoux can be used to characterize electric motors: rotation speed, efficiency, motor torque, etc. The software sensor can be accessed with a smartphone or tablet via the PEL100 wANDROID application.

Available for download free of charge.







## ULTRA-COMI

### ALL THE PEL100 MODELS ARE EQUIPPED WITH MULTIPLE COMMUNICATION MODES: ETHERNET AND USB PORTS, AS I

Max 0.003 u

The **PEL104** and PEL106 also offer **Wifi** communication and **3G/GPRS**. The **3G/GPRS** mode allows users to insert a SIM card in the PEL for remote co automatically receive an email for real-time notifications.

## RD Server

By positioning **PEL100**s on the different electrical feeders, it is possible and even simple to size the relative weight of each line in terms of overall consumption, define a load profile for the installation and thus determine the priorities for the improvements to be made. When access to the **PEL100** is complex because of the protective systems on today's IT systems, and when you're far from the logger, our solution lets you view the measurements remotely, via internet, without endangering the existing protective IT systems.





# Wifi

The **PEL104** and **PEL106** are equipped with a Wifi interface.v This means they are accessible from any PC by means of the PEL Transfer software. The **PEL104** and **PEL106** can be configured as a Wifi access point operating on the 2.4 GHz radio frequency band, allowing you to monitor the measurements in real time with a PC, smartphone, tablet, ...

PR P

# **G**<sub>PRS</sub>

As measurement campaigns are usually spread over a period of several days or weeks, it is important to check that the measurements are proceeding correctly. With their SIM card, the **PEL104** and **PEL106** communicate remotely, saving you time because you no longer have to go from one logger to the next to check each one. This makes it easy to recover the 10-minute consumption data on an electrical feeder.

## MUNICATING

### **NELL AS BLUETOOTH.**

nnection via a GPRS-3G link. It is also possible to access a PEL104 or PEL106 via an IRD server. In this way, when an alarm is triggered, the user can





H 133 ▲ 620,5 ▲ 619,7 ▲ IN 26,59 ▲ N № ▲ ∞ ● ≠ Current

Max 0.003 U





# Measurements & functions

The PEL100 power and energy loggers perform the following measurements:

- RMS and DC measurements with 128 samples/cycle simultaneously on each phase
- AC and/or DC voltages up to 1,000 V
- Analogue measurements
- Measurements on motors
- Self-powering via the phase
- Current up to 10 kA AC or 5 kA DC (depending on the current sensor).
- The PEL100 models offer a wider measurement range by using voltage and current ratios (up to 650,000 V / 25,000 A)
- Power values from 10 W/var/VA to 10 GW/Gvar/GVA
- Energy values up to 4 EWh / 4 EVAh / 4 Evarh & total energy (4 quadrants)
- Breakdown of energy losses
- Characterization of electric motors
- Phase data: cos φ, tan Φ, power factor (PF)
- Crest factor
- THD calculation for currents and voltages
- Harmonics up to the 50th order for currents and voltages
- DC, 50 Hz, 60 Hz and 400 Hz measurements
- Recording of the measurements and calculation results on the SD card
- Automatic recognition of the type of sensors connected
- Numerous network types supported: split-phase, three-phase with or without neutral, etc.
- Communications: USB, Bluetooth, Ethernet, Wifi, GSM 3G, GPRS
- Software for data transfer, real-time communication with a PC and report generation



FUNCTIO





Configure your preferred

communication mode directly in the instrument.





# **P**EL Transfer software

This application software lets you:

- Configure the PEL100
- Check the connections before starting to record
- Download the measurements recorded in the PEL100
- View the various measurement results and analyses

With the comprehensive DataView® processing software, it is also possible to create certified or customized reports.

C

In this way, DataView® helps you to generate your energy consumption reports more easily.

Our PEL Transfer software performs mathematical processing on the power measurement campaigns and automatically breaks down all the losses detected.



Configuration of alarms

Configuration of L452 loggers

Configuration of IRD Server

**C**urrent sensors compatible with the PEL 100 models

			MA194-250	1		0	0	R		Č,	
Model	MN93	MN 93A	MA194-350 MA194-1000	E3N	PAC93	A193-450	A193-800	C193	J93	MA196	A196-610
Measurement range	500 mA to 200 Aac	0,005 Aac to 5 Aac 0,2 Aac to 100 Aac	200mA to 10kAac	50 mA to 10 Aac/dc 100 mA to 100 Aac/dc	1 A to 1000 Aac 1 A to 1300 Adc	200 mA to 10 kAac	200 mA to 10 kAac	1 A to 1000 Aac	50 A to 3500 Aac 50 A to 5000 Adc	100 mA to 10 kAac	100 mA to 10 kAac
Clamping Ø / length	20 mm	20 mm	Ø 70/250 mm Ø 100/350 mm Ø 300/1000 mm	11.8 mm	1 x Ø 39 mm 2 x Ø 25 mm	Ø 140 mm / 450 mm	Ø 70/250 mm / 800 mm	52 mm	72 mm	Ø 100 mm / 350 mm	Ø190mm/ 610mm
IEC 61010	600 V CAT III / 300 V CAT IV		1000V CATIII / 600V CATIV	600 V CAT III / 300 V CAT IV	600 V CAT III / 300 V CAT IV		/ CAT III / / CAT IV	600 V CAT IV	600 V CAT III / 300 V CAT IV	1000 V CAT III / 600 V CAT IV	1000 V CAT III / 600 V CAT IV

## **SPECIFICATIONS**

Models	PEL102	PEL103	PEL104	PEL106			
Display	None	None With quadruple digital display					
Types of installations	Single-p	urations					
Number of channels	3 voltage	4 voltage inputs, 4 current inputs					
Measurements							
Network frequency	DC, 50 Hz, 60 Hz and 400 Hz						
Voltage (measurement ranges)	Voltage (measurement ranges) 10.00 -1,000 Vac/oc						
Current (depending on sensors) (measurement ranges)							
Calculated measurements							
Ratio	/ up to 25,000 A						
Power	10 W to 10 GW / 10 var to 10 Gvar / 10 VA to 10 GVA						
Energy							
Phase							
Harmonics							
Additional functions		Ye					
Phase sequence							
Min / Max							
Mounting		Hook (option)					
Recording							
Sampling / Acquisition interval / Aggregation		1 measurement/s - from 1 min to 60 min 5 measurements/s -					
Memory		SD card, 8 GB (SD-HC card up to 32 GB)					
Communication	Ethernet, Blue	tooth and USB	Ethernet, Bluetooth,				
Power supply	110	Power supply via the phase 1,000 V AC/DC					
Safety		IEC 61010 1000 V CAT IV					
Mechanical specifications		256 x 125 x 37 mm without sensor					
Dimensions		245 x 270 180 mm without sensor					
Weight		<3400 g					
Casing		IP67					

### **STATE AT DELIVERY:**

### PEL102 or PEL103 delivered with:

1 carrying bag, 4 measurement cables (straight-banana/straight-banana 3 m long - black), 4 crocodile clips (black), 1 set of plugs (for the extremities of the cables and current sensors), 1 mains cable, 1 x 8 GB SD card, 1 USB cable, 1 SD–USB adapter, PC software (PEL Transfer), 1 user's manual (on CD), 1 safety datasheet, 1 quick start guide.

### PEL104 with:

1 carrying bag, 4 voltage cables, 4 crocodile clips, 1 set of rings/inserts, 1 x 600 V mains adapter, 1 SD card, 1 SD - USB adapter, 1 USB cable, PC PEL TRANSFER software & user's manual to download from the website, 1 quick start guide.

#### PEL106 with:

1 bag for the accessories, 5 x IP67 voltage cables, 5 lockable crocodile clips, 1 set of rings/inserts, PC software (PEL Transfer), 1 SD card, 1 SD -USB adapter, 1 USB cable, PC PEL TRANSFER software & user's manual to download from the website, 1 quick start guide.



### **ACCESSORIES:**

C193 clamp  P01120323B    MN93 clamp  P01120425B    MN93 clamp  P01120434B    E3N clamp  P01120043A    E3N clamp  P01120043A    E3N clamp  P01120043A    E3N clamp  P01120043A    E3N adapter  P01102081    PAC93 clamp  P01120079B    J93 clamp  P01120079B    J93 clamp  P01120526B    AmpFlex® A193-450 clamp  P01120531B    AmpFlex® A196-610 clamp, IP67  P01120554    MiniFlex® MA194-250 clamp  P01120592    MiniFlex® MA194-350 clamp  P01120592    MiniFlex® MA194-350 clamp, IP67  P01120592    MiniFlex® MA194-350 clamp, IP67  P01120593    MiniFlex® MA194-350 clamp, IP67  P01120594    MiniFlex® MA194-350 clamp, IP67  P01120594    MiniFlex® MA194-300 clamp, IP67  P01120594    Mains power cable  P01295174    PEL100 mains adapter  P01102174    Cables/clamps kit (x4)  P01295476    Set of plugs/rings  P01102080    5 A adapter  P01102095    Sadapter  P01102095		
MN93 clamp  P01120425B    MN93A clamp  P01120434B    E3N clamp  P01120434B    E3N clamp  P01120434B    E3N clamp  P01120043A    E3N adapter  P01120043A    PAC93 clamp  P01120079B    J93 clamp  P01120179B    J93 clamp  P01120526B    AmpFlex® A193-450 clamp  P01120526B    AmpFlex® A196-610 clamp, IP67  P01120554    MiniFlex® MA194-250 clamp  P01120593    MiniFlex® MA194-350 clamp  P01120593    MiniFlex® MA194-350 clamp, IP67  P01120594    MiniFlex® MA194-350 clamp, IP67  P01120568    Cables kit (x 5) BB196, IP67  P01295479    Mains power cable  P01295174    PEL100 mains adapter  P0102174    Cables/clamps kit (x4)  P01295476    Set of plugs/rings  P01102080    5 A adapter	C193 clamp	P01120323B
MN93A clamp    P01120434B      E3N clamp    P01120043A      E3N adapter    P01102081      PAC93 clamp    P01120079B      J93 clamp    P01120079B      J93 clamp    P01120079B      J93 clamp    P0112010      AmpFlex® A193-450 clamp    P01120526B      AmpFlex® A193-800 clamp    P01120531B      AmpFlex® A194-50 clamp    P01120593      MiniFlex® MA194-250 clamp    P01120593      MiniFlex® MA194-350 clamp    P01120592      MiniFlex® MA194-350 clamp    P01120592      MiniFlex® MA194-350 clamp    P01120592      MiniFlex® MA194-350 clamp    P01120592      MiniFlex® MA196-350 clamp, IP67    P01120594      MiniFlex® MA196-350 clamp, IP67    P01295479      Mains power cable    P01295174      PEL100 mains adapter    P01295174      PEL100 mains adapter    P01102174      Cables/clamps kit (x4)    P01295476      Set of plugs/rings    P01102080      5 A adapter    P01102080      5 A adapter    P01102085      Bag no. 23    P01298078<		
E3N clamp  P01120043A    E3N adapter  P01102081    PAC93 clamp  P01120079B    J93 clamp  P01120079B    J93 clamp  P01120110    AmpFlex® A193-450 clamp  P01120526B    AmpFlex® A193-610 clamp  P01120531B    AmpFlex® A194-50 clamp  P01120554    MiniFlex® MA194-250 clamp  P01120593    MiniFlex® MA194-350 clamp  P01120592    MiniFlex® MA194-350 clamp  P01120592    MiniFlex® MA194-350 clamp  P01120594    MiniFlex® MA196-350 clamp  P01120594    MiniFlex® MA196-350 clamp  P01120568    Cables kit (x 5) BB196, IP67  P01295479    Mains power cable  P01295174    PEL100 mains adapter  P01102174    Cables/clamps kit (x4)  P01295476    Set of plugs/rings  P01102080    5 A adapter  P01102080    5 A adapter  P01102080    5 A adapter  P01102095    Bag no. 23  P01298078    Pole-mounting kit  P01102146		
E3N adapter		
PAC93 clamp  P01120079B    J93 clamp  P01120110    AmpFlex® A193-450 clamp  P01120526B    AmpFlex® A193-600 clamp  P01120531B    AmpFlex® A196-610 clamp, IP67  P01120593    MiniFlex® MA194-250 clamp.  P01120593    MiniFlex® MA194-250 clamp.  P01120593    MiniFlex® MA194-250 clamp.  P01120592    MiniFlex® MA194-1.000 clamp.  P01120594    MiniFlex® MA196-350 clamp, IP67  P01120594    Mains power cable  P01295174    PEL100 mains adapter.  P01102174    Cables/clamps kit (x4)  P01295476    Set of plugs/rings  P01102080    5 A adapter  P01102080    5 A adapter  P01102055    Bag no. 23  P01295078    Pole-mounting kit  P01295478		
J93 clamp  P01120110    AmpFlex® A193-450 clamp  P01120526B    AmpFlex® A193-800 clamp  P01120531B    AmpFlex® A196-610 clamp, IP67  P01120554    MiniFlex® MA194-250 clamp  P01120593    MiniFlex® MA194-350 clamp  P01120592    MiniFlex® MA194-1000 clamp  P01120594    MiniFlex® MA194-50 clamp, IP67  P01120594    MiniFlex® MA196-350 clamp, IP67  P01295479    Mains power cable  P01295479    Mains power cable  P01295474    PEL 100 mains adapter  P0102174    Cables/clamps kit (x4)  P01295476    Set of plugs/rings  P01102080    5 A adapter  P01102080    5 A adapter  P01102095    Bag no. 23  P01298078    Pole-mounting kit  P01102146		
AmpFlex® A193-450 clamp  P01120526B    AmpFlex® A193-800 clamp  P01120531B    AmpFlex® A196-610 clamp, IP67  P01120554    MiniFlex® MA194-250 clamp  P01120593    MiniFlex® MA194-350 clamp  P01120592    MiniFlex® MA194-350 clamp  P01120592    MiniFlex® MA194-350 clamp  P01120594    MiniFlex® MA196-350 clamp, IP67  P01120568    Cables kit (x 5) BB196, IP67  P01295479    Mains power cable  P01295174    PEL 100 mains adapter  P0102174    Cables/clamps kit (x4)  P01295476    Set of plugs/rings  P01102080    5 A adapter  P01102080    5 A adapter  P01102080    5 A adapter  P01102095    Bag no. 23  P01298078    Pole-mounting kit  P01102146		
AmpFlex® A193-800 clamp  P01120531B    AmpFlex® A196-610 clamp, IP67  P01120554    MiniFlex® MA194-250 clamp  P01120593    MiniFlex® MA194-350 clamp  P01120592    MiniFlex® MA194-350 clamp  P01120594    MiniFlex® MA194-350 clamp  P01120594    MiniFlex® MA196-350 clamp, IP67  P01120568    Cables kit (x 5) BB196, IP67  P01295479    Mains power cable  P01295174    PEL100 mains adapter  P0102174    Cables/clamps kit (x4)  P01295476    Set of plugs/rings  P01102080    5 A adapter  P01102080    5 A adapter  P01102080    5 A adapter  P01102080    5 A adapter  P01102080    5 A odapter  P01102080    6 ag no. 23  P01298078    Pole-mounting kit  P0102146		
AmpFlex® A196-610 clamp, IP67.  P01120554    MiniFlex® MA194-250 clamp.  P01120593    MiniFlex® MA194-350 clamp.  P01120592    MiniFlex® MA194-350 clamp.  P01120594    MiniFlex® MA194-350 clamp.  P01120592    MiniFlex® MA196-350 clamp.  P01120594    MiniFlex® MA196-350 clamp, IP67  P01120568    Cables kit (x 5) BB196, IP67  P01295479    Mains power cable  P01295174    PEL100 mains adapter  P01295174    Cables/clamps kit (x4)  P01295476    Set of plugs/rings  P01102080    5 A adapter  P01102080    5 A adapter  P01102080    5 Bay 0. 23  P01298078    Pole-mounting kit  P01298078		
MiniFlex® MA194-250 clamp.  P01120593    MiniFlex® MA194-350 clamp.  P01120592    MiniFlex® MA194-1.000 clamp.  P01120594    MiniFlex® MA196-350 clamp.  P01120594    MiniFlex® MA196-350 clamp.  P01120594    MiniFlex® MA196-350 clamp.  P01120568    Cables kit (x 5) BB196, IP67  P01295479    Mains power cable  P01295174    PEL100 mains adapter.  P01102174    Cables/clamps kit (x4)  P01295476    Set of plugs/rings  P01102080    5 A adapter  P01102080    5 A adapter  P01102080    5 Bag no. 23  P01298078    Pole-mounting kit  P01102146		
MiniFlex® MA194-350 clamp.    P01120592      MiniFlex® MA194-1.000 clamp.    P01120594      MiniFlex® MA196-350 clamp, IP67    P01120568      Cables kit (x 5) BB196, IP67    P01295479      Mains power cable    P01295174      PEL 100 mains adapter.    P01102174      Cables/clamps kit (x4)    P01295476      Set of plugs/rings    P01102080      5 A adapter    P01102080      5 A adapter    P01102080      5 A adapter    P01102080      5 A adapter    P01102080      5 A odapter    P01102080      5 A poltaware    P01102080      5 A odapter    P01102085      Bag no. 23    P01298078      Pole-mounting kit    P01102146		
MiniFlex® MA194-1.000 clamp.  P01120594    MiniFlex® MA196-350 clamp, IP67  P01120568    Cables kit (x 5) BB196, IP67  P01295479    Mains power cable  P01295174    PEL 100 mains adapter.  P01102174    Cables/clamps kit (x4)  P01295476    Set of plugs/rings  P01102080    5 A adapter  P0110295    DataVIEW® software  P01102095    Bag no. 23  P01298078    Pole-mounting kit  P01102146		
MiniFlex® MA196-350 clamp, IP67		
Cables kit (x 5) BB196, IP67		
Mains power cableP01295174PEL 100 mains adapterP01102174Cables/clamps kit (x4)P01295476Set of plugs/ringsP011020805 A adapterP01101959DataVIEW® softwareP01102095Bag no. 23P01298078Pole-mounting kitP01102146		
PEL100 mains adapter.		
Cables/clamps kit (x4)    P01295476      Set of plugs/rings    P01102080      5 A adapter    P01101959      DataVIEW® software    P01102095      Bag no. 23    P01298078      Pole-mounting kit    P01102146		
Set of plugs/rings    P01102080      5 A adapter    P01101959      DataVIEW® software    P01102095      Bag no. 23    P01298078      Pole-mounting kit    P01102146		
5 A adapter		
DataVIEW® software    P01102095      Bag no. 23    P01298078      Pole-mounting kit    P01102146		
Bag no. 23		
Pole-mounting kitP01102146		
0		
	REFERENCES TO ORDER:	

### PEL102 without current sensors.....P01157152 PEL103 without current sensors ......P01157153 PEL104 without current sensors.....P01157154 PEL106 without current sensors ......P01157165

FRANCE **Chauvin Arnoux** 

12-16 rue Sarah Bernhardt 92600 Asnières-sur-Seine Tel: +33 1 44 85 44 38 Fax: +33 1 46 27 95 59 export@chauvin-arnoux.fr www.chauvin-arnoux.com

### **UNITED KINGDOM Chauvin Arnoux Ltd**

Unit 1 Nelson Ct, Flagship Sq, Shaw Cross Business Pk Dewsbury, West Yorkshire - WF12 7TH Tel: +44 1924 460 494 Fax: +44 1924 455 328 info@chauvin-arnoux.co.uk www.chauvin-arnoux.com

**Middle East Chauvin Arnoux Middle East** P.O. BOX 60-154 1241 2020 JAL EL DIB - LEBANON Tel: +961 1 890 425 Fax: +961 1 890 424 camie@chauvin-arnoux.com www.chauvin-arnoux.com

