

TECHNICAL DATA

Fluke i3000s AC Current Clamp



Key features

The i3000s is a clamp-on AC Current Clamp for use with oscilloscopes and multimeters with banana input using the supplied Dual Banana to BNC Adapter.

Product overview: Fluke i3000s AC Current Clamp

Very High AC Current Clamp

Fluke Current clamps are the ideal tools to extend the current ranges of Fluke tools.

The i3000s is a clamp-on AC Current Clamp for use with oscilloscopes and multimeters with banana input using the supplied Dual Banana to BNC Adapter. The clamp is optimized for measurement on power distribution systems.

Specifications: Fluke i3000s AC Current Clamp

Specifications	
Nominal current range	30 A 300A 3000A

Continuous current range	1 A - 30 A 1 A - 300 A 1 A - 3000 A
Maximum non-destructive current	4000 A
Lowest measureable current	1 A
Basic accuracy	2% + 2 A (48-65 Hz) % reading + floorspec
Useable frequency	10 Hz - 100 kHz
Output level(s)	10 mv/A 1 mv/A 0.1 mv/A
<b>Safety Specifications</b>	
Safety	CAT III, 600 V
Maximum voltage	600 V AC
<b>Mechanical and General Specifications</b>	
Warranty	1 year
Maximum conductor diameter	64 mm
Output cable length	2.1 m
BNC adapter	Yes

## Ordering information



### **Fluke-i3000s**

Fluke i3000s AC Current Clamp

---

**Fluke.** *Keeping your world up and running.®*

**Fluke (UK) Ltd.**  
52 Hurricane Way  
Norwich, Norfolk  
NR6 6JB  
United Kingdom  
Tel.: +44 (0)20 7942 0708  
E-mail: [cs.uk@fluke.com](mailto:cs.uk@fluke.com)  
[www.fluke.com/en-gb](http://www.fluke.com/en-gb)

©2023 Fluke Corporation. All rights reserved.  
Data subject to alteration without notice.  
12/2023

**Modification of this document is not permitted  
without written permission from Fluke Corporation.**